

PARTS NEWS

PARTS DIVISION

CR750 RACING PARTS

H/C	Part Number	Description	H/C	Part Number	Description
30166	11631-300-970	Cover, Dynamo	28899	18350-300-970	Megaphone II Ex
USED IN SET WITH 13000-300-971 & 31100-286-971			28900	18400-300-970	Megaphone III
37356	12100-300-970	Cylinder Comp. (61.5mm)	28901	18450-300-970	Megaphone IV
37357	12191-300-970	Gasket, cylinder	28877	22870-300-970	Cable, clutch
27725	12200-300-970	Head, cylinder	28942	23121-300-970	Chain, primary
27739	13000-300-970	Crankshaft Assy.	28848	23210-300-970	Shaft, main
30167	13000-300-971	Crankshaft Comp.	28849	23421-300-970	Gear, low C/S
USED IN SET WITH 11631-300-970 & 31100-286-971			28850	23431-300-970	Gear, 2nd & 3rd M/S
27741	13101-300-970	Piston A	28851	23440-300-970	Gear, 2nd C/S
28819	13102-300-970	Piston B	28852	23450-300-970	Gear, 4th M/S
28830	13121-300-970	Ring, piston top	28853	23460-300-970	Gear, 3rd C/S
28831	13141-300-970	Ring, piston oil	28854	23471-300-970	Gear, 4th C/S
30202	13210-300-970	Rod Comp, connecting	28855	23481-300-970	Gear, top M/S
30203	13213-300-970	Bolt, connecting	28856	23491-300-970	Gear, top C/S
37355	14000-300-970	Tensioner Set, cam chain	28857	24211-300-970	Fork right
28844	14101-300-970	Camshaft	28943	24301-300-970	Drum, gear shift
28947	14401-286-971	Chain, cam	28944	24321-300-970	Cam, gear shift
37358	14510-300-970	Base, tensioner	28932	24701-300-970	Pedal, gear
37359	14520-300-970	Tensioner, cam chain	30125	24750-300-970	Pedal Comp., gear change
37360	14523-300-970	Holder, tensioner	30116	24754-300-970	Bolt, change connect
37361	14524-300-970	Washer, 7mm	30124	24760-300-970	Arm Comp., R/H change connect
37362	14525-300-970	Nut, tensioner lock	30123	24763-300-970	Collar, R/H change connect shaft
37363	14537-300-970	Guide, tensioner	30119	24764-300-970	Bearing, special
37364	14538-300-970	Bolt, tensioner lock	30122	24765-300-970	Holder, ball joint
37365	14541-300-970	Spring, tensioner	30120	24766-300-970	Shaft, change connect
37366	14611-300-970	Guide A, cam chain	30118	24767-300-970	Collar, L/H change connect shaft
37367	14612-300-970	Guide B, cam chain	30117	24770-300-970	Arm Comp., L/H change upper
37368	14615-300-970	Holder, tensioner base	30115	24780-300-970	Arm Comp., L/H change under
37369	14617-300-970	Pin, cam chain guide	28858	30200-300-970	Cam, points
28824	14711-300-970	Valve, inlet	28937	30505-300-970	Sub Cord, coil
28825	14721-300-970	Valve, exhaust	30160	30700-300-970	Terminal Assy. A
28826	14751-300-970	Spring, valve in	30161	30710-300-970	Terminal Assy. B
28827	14761-300-970	Spring, valve ex.	30168	31100-286-971	Generator Assy. A/C
28946	15145-300-970	Spring, valve	*USED IN SET WITH 11631-300-970 & 13000-300-971*		
28978	15510-300-970	Hose Comp. A, oil	28859	31100-300-970	A.C. Generator Assy.
28979	15520-300-970	Hose Comp. B, oil	28939	32100-300-970	Harness, wire
28980	15530-300-970	Hose Comp. C, oil	28938	35300-300-971	Switch Assy.
30200	15921-300-970	Bolt, gauge	28928	37240-300-970	Tachometer Assy.
28845	16100-300-970	Carb. Assy. C35682	28929	37260-300-970	Cable, tachometer
(SUPERSEDED BY 16100-300-971)			28992	37500-300-970	Meter Assy.
35682	16100-300-971	Carb. Assy., CR	28991	37501-300-970	Ring
28846	16211-300-970	Insulator A Carb	30201	37511-300-970	Connector, oil pressure
28847	16212-300-970	Insulator B	28936	40530-300-970	Chain, drive
28860	16950-300-970	Cock Assy., fuel	28916	41201-300-970	Sprocket, 44T
28866	16997-300-970	O-Ring, 125x35	28917	41202-300-970	Sprocket, 46T
28861	17500-300-970	Tank Comp., fuel	28918	41203-300-970	Sprocket, 48T
28862	17502-300-970	Clip, fuel tube	29007	41204-300-970	Sprocket, 42T
28863	17503-300-970	Band, fuel tank	29008	41205-300-970	Sprocket, 43T
28864	17504-300-970	Sponge, tank	29009	41206-300-970	Sprocket, 45T
28865	17505-300-970	Pad, fuel tank	29010	41207-300-970	Sprocket, 47T
29764	17600-300-970	Tank Comp., fuel	31590	41231-300-970	Retainer, bearing
28874	17910-300-970	Cable A, throttle	31582	42000-300-970	Wheel Assy., rear
28875	17912-300-970	Cable B, throttle	31583	42100-300-970	Brake Assy., rear
28904	17917-300-970	Lock Nut, 7mm	31584	42200-300-970	Hub Assy., rear brake
28898	18300-300-970	Megaphone 1 ex	28919	42311-300-970	Collar
28920	42313-300-970	Collar, side	28988	55107-300-970	Bracket, setting
28921	42601-300-970	Hub Comp., rear	28981	55200-300-970	Case, breather
28922	42606-300-970	Spoke A, rear	28940	56100-300-970	Cooler Comp., oil
28923	42607-300-970	Spoke B, wheel	28941	56101-300-970	Stay, oil cooler
31591	42620-300-970	Collar, rear axle	28896	61100-300-970	Fender, front
28924	42701-300-970	Rim, rear wheel	29000	64100-300-970	Fairing
28902	43100-300-970	Panel Assy., rear	29001	64101-286-970	Lens, fairing
31592	43102-300-970	Washer, brake pin	29004	64210-300-970	Piece C, right stay
28909	43120-300-970	Shoe, rear brake	29012	64214-300-970	Fastener Comp.
28913	43141-300-970	Cam, rear brake	29005	64220-300-970	Piece C, left stay

MODEL

CR750

APPLICATION

ALL

FILE UNDER

Promotional

BULLETIN NO.

M74080501

ISSUE DATE

8-5-74

H/C	Part Number	Description	H/C	Part Number	Description
28914	43151-300-970	Spring, brake	29003	64231-300-970	Stay A, fairing
31585	43200-300-970	Panel Assy., rear brake	29002	64232-288-970	Holder, fairing
28910	43411-300-970	Arm A, rear brake	29006	64236-300-970	Stay D, fairing
28908	43421-300-970	Arm B, rear brake	29011	64245-300-970	Screw, fairing
28903	43451-300-970	Rod, rear brake	28897	77201-300-970	Stay, seat
31593	43452-300-970	Nut, brake rod lock	28989	77300-300-970	Seat Comp.
28037	43460-300-970	Cable, rear brake	31588	90014-300-970	Bolt, rotor set
30128	43470-300-971	Cable comp., rear brake	28933	90101-300-970	Bolt, hex., 8x25
31594	43472-300-970	Spring, brake arm return	28915	90102-300-970	Bolt, pedal
28969	43473-300-970	Pin, rear brake	28970	90103-300-970	Bolt, lock, 8x52
35109	44301-300-971	Axle, front wheel	28971	90104-300-970	Bolt, 8x45
28889	44311-300-970	Collar, front wheel	28972	90105-300-970	Bolt, 8x40
28890	44606-300-970	Spoke A, front	05131	90114-273-000	Bolt, lever
28891	44607-300-970	Spoke B, front	28887	90122-300-970	Bolt, disc
28976	44642-300-970	Spacer, plate	28925	90128-300-970	Bolt, sprocket
28892	44701-300-970	Rim, front wheel	28974	90155-300-970	Bolt, engine hanger
31586	44701-300-971	Rim, front wheel	30127	90301-300-970	Nut, lock (R), 8mm
19464	45115-300-030	Holder, caliper	30128	90302-300-970	Nut, lock (L), 8mm
19465	45116-300-030	Pin, holder	35110	90305-300-971	Sleeve, right front axle
31494	45117-341-700	Bolt, adjusting	28905	90321-300-970	Nut, left brake
19467	45119-300-020	Spring, adjust	28926	90523-300-970	Washer, 8mm
31587	45120-300-970	Disk, front brake	28973	90665-300-970	Circlip, external, 115mm
28879	45125-300-970	Hose B, front brake	31589	90741-300-970	Pin, knock, 4mm
28882	45127-300-970	Joint, 3-way	*USED WITH 13000-300-971*		
28880	45128-300-970	Hose A, front brake	28945	90811-300-970	Plug, rubber
28881	45130-300-970	Clip	19472	91259-300-000	O-Ring, 10x1.7
19437	45146-300-000	Packing, hose	07103	91317-703-000	O-Ring, 6x1.7
28885	45200-300-970	Caliper Assy., right	35692	99101-357-1000	Jet, main No. 100
28886	45204-300-970	Joint, right holder	35693	99101-357-1050	Jet, main No. 105
28883	45228-300-970	Pipe, right front	35694	99101-357-1100	Jet, main No. 110
28884	45245-300-970	Clip, right brake hose	35695	99101-357-1150	Jet, main No. 115
28888	45500-300-970	Cylinder Assy.	34168	99101-357-1200	Jet, main No. 120
28907	46500-300-970	Pedal, rear brake	34170	99101-357-1250	Jet, main No. 125
28911	46501-300-970	Collar, brake pedal	34172	99101-357-1300	Jet, main No. 130
30130	50118-300-970	Collar, ball joint	35696	99101-357-1350	Jet, main No. 135
28975	50137-300-970	Plate B	32837	99101-357-1400	Jet, main No. 140
28930	50148-300-970	Bracket, right step	32835	99101-357-1450	Jet, main No. 145
28931	50149-300-970	Bracket, left step	32078	99101-357-1500	Jet, main No. 150
28998	50200-300-970	Stopper A, handle	35683	99105-357-2500	Jet, air No. 250
28999	50201-300-970	Stopper B, handle	35684	99105-357-2550	Jet, air No. 255
30121	50356-300-970	Bracket, rear engine hanger	35685	99105-357-2600	Jet, air No. 260
28934	50616-300-970	Arm, right step	35686	99105-357-2650	Jet, air No. 265
28935	50642-300-970	Arm, left step	35687	99105-357-2700	Jet, air No. 270
35107	51400-300-971	Fork Assy., right front	35688	99105-357-2750	Jet, air No. 275
35108	51500-300-971	Fork Assy., left front	35689	99105-357-2800	Jet, air No. 280
28927	52400-300-970	Cushion Assy., rear	35690	99105-357-2850	Jet, air No. 285
28867	53100-300-970	Pipe, right handle	35691	99105-357-2900	Jet, air No. 290
28868	53106-300-970	Pipe, left handle	28948	99199-287-1000	Jet, main No. 100
28871	53141-300-970	Pipe, throttle	28949	99199-287-1050	Jet, main No. 105
28869	53165-283-970	Rubber, right grip	28950	99199-287-1100	Jet, main No. 110
28870	53166-288-970	Rubber, left grip	28951	99199-287-1150	Jet, main No. 115
28872	53167-300-970	Housing, winder	28952	99199-287-1200	Jet, main No. 120
28873	53168-300-970	Housing, winder	28953	99199-287-1250	Jet, main No. 125
36531	53170-369-003	Lever, right handle	28954	99199-287-1300	Jet, main No. 130
28876	53172-300-971	Bracket, left lever	28955	99199-287-1350	Jet, main No. 135
36533	53190-369-700	Lever, left handle	28956	99199-287-1400	Jet, main No. 140
28878	53192-300-970	Loose, adj. bolt	28957	99199-287-1450	Jet, main No. 145
28895	53230-300-970	Bridge, fork top	28958	99199-287-1500	Jet, main No. 150
28990	53232-300-970	Bracket, setting	34188	98069-60711	Spark Plug *D10ES*
28995	53700-300-970	Damper, steering	29759	98069-62410	Spark Plug *D12E*
28996	53710-300-970	Bracket A	28959	99102-25004	Jet, air No. 250
28997	53720-300-970	Bracket B	28960	99102-25504	Jet, air No. 255
04744	53731-268-810	Rubber, steering damper	28961	99102-26004	Jet, air No. 260
28977	55100-300-970	Tank Comp., oil	28962	99102-26504	Jet, air No. 265
28982	55101-300-970	Piece A, stay	28963	99102-27004	Jet, air No. 270
28983	55102-300-970	Piece B, stay	28964	99102-27504	Jet, air No. 275
28984	55103-300-970	Piece C, stay	28965	99102-28004	Jet, air No. 280
28985	55014-300-970	Rail, R/H tank	28966	99102-28504	Jet, air No. 285
28986	55105-300-970	Rail, L/H tank	28967	99102-29004	Jet, air No. 290
28987	55106-300-970	Plate, stay			